



BIRD BASKETBALL HOOP

Instruction

Maintenance & Instructions

1. Check all nuts & bolts for tightness & tighten when required, if any. Please keep this instruction for future reference.
2. Check all coverings and bolts for sharp edges and replace them when required, if any.
3. Replace when required by the manufacturer's instructions.
4. Before each use, please check whether the components are firm and intact. Please wipe with a dry cloth regularly.

Caution

1. Ensure the product is in good condition and all parts are complete before use.
2. After adult installation, please make sure all parts are securely assembled before allowing children to use it.
3. Do not let children play with broken, damaged, or deformed toys to prevent accidents.
4. Keep packaging materials away from children, as they are not toys and may pose a danger.
5. This toy is designed for domestic use and is suitable for both indoor and outdoor play.


WARNINGS

1. This product must be assembled by an adult. Keep all parts and tools away from children until fully assembled.
2. The package contains small parts and hardware that pose a choking risk and may have sharp edges or points. Handle with care.
3. This product is designed for children aged 18 months and above.
4. To prevent serious injury, adult supervision is mandatory at all times. Never leave children unattended during use.
5. Ensure the equipment is on a level surface, at least 7 feet away from pools, power lines, overhangs, other playground equipment, driveways, or roads.
6. Do not attach objects like jump ropes, chains, clotheslines, pet leashes, or cables to the slide. These may cause strangulation or other hazards.

Warning! Not suitable for children under 3 years. Contains small parts, Choking hazard.

Part Details

List of Parts	No.
Basketball board with hoop	1
Basketball net	1
Deflated Basketball	1
Air Pump with Nozzle	1
Toss Ring hanger with Nut	1
Toss Ring	3
Key	1
Sticker Set	1
Instruction Manual	1



Basketball Board with Hoop x 1



Deflated Basketball x 1



Toss Ring Hanger with Nut x 1



Key x 1




Basketball Net x 1



Air Pump x 1



Toss Ring x 3



Instruction Manual x 1



Sticker Set x 1

Model No:70125

3+
YEARS



Customer Support



Assembly Video

Before starting the assembly, please ensure that the part quantity matches the numbers listed in the manual. If you find any discrepancies in the part count or encounter any product-related issues, feel free to reach out to us at +918221001033 or connect with us via WhatsApp in between 9:30-6PM, Monday to Saturday. We're here to assist you!

IS : 9873 - PART I




CM/L - 9512463818

For details of BIS certification, please visit www.bis.gov.in

DISCLAIMER: ACTUAL PRODUCT COLOR MAY VARY FROM THAT SHOWN IN THE IMAGE

1 STEP

Required Assembly Part



Before starting the assembly, lay out a carpet on the floor to prevent scratches during assembly.




Take the basketball board with hoop and the toss ring hanger with nut. Unscrew the nut from the ring hanger as shown in the image.

Insert the toss ring hanger, thread side first, into the designated hole on the front of the basketball board as shown in the image. Secure it by tightening the nut using the provided key. Basketball hoop is ready for further operations.

2 STEP

Required Assembly Part



Take the basketball board with Hoop and the basketball net. Secure the net to the basketball hoop as shown in image.

Fix the Eye and the sticker as shown in image. Basketball board is ready to hang on wall.

Secure the assembled basketball board to a wall by hanging it on a nail fixed at an appropriate height based on your child's height, using the designated hanging hole on the back of the board.



Attach the nozzle to the air pump as shown in the image. Insert the nozzle into the ball valve and inflate the ball.



Score big and play more with this dual-purpose Basketball Hoop and Ring Toss—double the fun in one game!