



MOON BASKETBALL

Instructions

Maintenance:

- Before each use, ascertain that all the parts are securely fastened.
- Always wipe the product with a plane, dry cloth regularly and avoid using harsh chemicals.

Caution:

- The product must be assembled by an adult only. Keep all the parts out of the reach of kids until the product is fully assembled.
- Always use the product on an even surface. Using it on concrete or a rough surface can make it unsteady and may cause injuries.
- Abstain from hanging on the basketball ring.
- Packaging materials are not safe to play with and should be kept away from kids.
- Adult supervision is recommended when kids are using the product.

Warnings:

- Always assemble on a non-abrasive surface, ideally a carpet, to avoid scratches and make sure there are no sharp objects placed nearby.
- Avoid over-tightening the nuts as it may cause damage to the parts.


Part Details




Base x 1



Basketball Backboard x 1



Big Nut x 3



Small Nut x 2




Key x 1




Instruction Manual x 1



Ball x 1



Ferrule Rod x 1



Football Stand x 1



Upper Support Pillar x 1



Lower Support Pillar x 1

List of Parts	No.
Base Panel	1
Basketball Backboard	1
Lower Support Rod	1
Upper Support Rod	1
Basketball Ring	1
Basketball Net	1
Ball	1
Instruction Manual	1
Football Stand	1
Ferrule Rod	1
Big Nut	3
Small Nut	2
Key	1

1
STEP

Assembly Instructions

Required Assembly Parts



Lower Support Pillar x 1



Key x 1



Small Nut x 2



Big Nut x 1



Ferrule Rod x 1



Football Stand x 1



Base Panel x 1

Before starting the assembly, lay out a carpet on the floor to avoid scratches.



Align the threaded pins at the base of the football stand with the designated slots on the base panel and push the football stand downwards, guiding the threaded pin through the slots. Put a small nut onto the end of the each threaded pin and tighten, securing both the stand and the base panel together.



Take the ferrule rod and fit it on the base panel at the position as shown in the image.
Note: Make sure the ferrule rod is placed correctly, following the orientation as shown in the image.



Model No: 70132

3+
YEARS



Scan to Connect

Before starting the assembly, please ensure that the part quantity matches the numbers listed in the manual. If you find any discrepancies in the part count or encounter any product-related issues, feel free to reach out to us at +918221001033 or connect with us via WhatsApp in between 9:30-6PM, Monday to Saturday. We're here to assist you!

IS : 9873 - PART I



CM/L - 9512463818

For details of BIS certification, please visit www.bis.gov.in

DISCLAIMER: ACTUAL PRODUCT COLOR MAY VARY FROM THAT SHOWN IN THE IMAGE

Align the threaded pin at the bottom of the lower support rod with the designated slot on the base panel and push the lower support rod downwards, guiding the threaded pin through the hole.

From the underside of the base panel, put a big nut onto the threaded pin of the lower support rod and tighten, securing the lower support rod to the base panel.



2 STEP

Required Assembly Parts



Subassembly (Step 1)



Basketball Backboard x 1



Big Nut x 2



Upper Support Rod x 1

Basketball Ring x 1



Basketball Net x 1



Align the bottom of the basketball backboard with the opening at the top of the upper support rod. Slide the basketball backboard downwards into the opening, ensuring it fits smoothly.

Align the bottom of the upper support with the top of the lower support rod of the subassembly (step 1) and firmly press the upper support rod downwards, securing both together.



Take the basketball net from the packaging, hold one of its loops with your fingers and wrap the loop around a pair of hooks. Move to the next pair of hooks and repeat the process, securing each loop of the net to the basketball ring.

Secure the basketball ring to the basketball backboard with two big nuts.



***Your Moon Basketball is now ready for use!
Start your kid's basketball journey today!***



You can adjust the height of the moon basketball to suit your needs. To raise the height:

1. Unlock the latch of the lower support rod.
2. Gently slide the upper support rod outwards to the desired height, aligning one of its height adjustment slots with the latch.
3. Close the latch to lock it into the selected height adjustment slot.

