



ROLLER COASTER

Instructions

Maintenance:

- Before each use, ascertain that all the parts are securely fastened.
- Always wipe the product with a plane, dry cloth regularly and avoid using harsh chemicals.

Caution:

- The product must be assembled by an adult only. Keep all the parts out of the reach of kids until the product is fully assembled.
- Always use the product on an even surface. Using it on concrete or a rough surface can make it unsteady and may cause injuries.
- Packaging materials are not safe to play with and should be kept away from kids.
- Adult supervision is recommended when kids are using the product.
- Keep this manual for future reference.

Warnings:

- Always assemble on a non-abrasive surface, ideally a carpet, to avoid scratches and make sure there are no sharp objects placed nearby.
- Avoid over-tightening the nuts as it may cause damage to the parts.

Part Details



Step Panel (Left & Right) x 2



Riding Track A x 1



Riding Track B x 1


List of Parts	No.
Step Panel (Left & Right)	2
Riding Track A	1
Riding Track B	2
Riding Track C	1
Coaster Car	2
Instruction Manual	1



Coaster Car x 1



Instruction Manual x 1



Riding Track C x 1

1
STEP

Assembly Instructions

Required Assembly Parts



Step Panel (Left & Right) x 2



Riding Track A x 1

Before starting the assembly, lay out a carpet on the floor to avoid scratches.



Place the left and right step panels opposite each other on the ground making sure they are a suitable distance apart to support the riding track.



Take the riding track A, align the open section on its underside with the grooves on the step panels and rest the riding track A on the step panels.

Note: Make sure the riding track A is positioned correctly, following the orientation as shown in the images above.

Model No: 21417

3+
YEARS



Scan to Connect

Before starting the assembly, please ensure that the part quantity matches the numbers listed in the manual. If you find any discrepancies in the part count or encounter any product-related issues, feel free to reach out to us at +918221001033 or connect with us via WhatsApp in between 9:30-6PM, Monday to Saturday. We're here to assist you!

IS : 9873 - PART I



CM/L - 9512463818

For details of BIS certification, please visit www.bis.gov.in

DISCLAIMER: ACTUAL PRODUCT COLOR MAY VARY FROM THAT SHOWN IN THE IMAGE

2 STEP

Required Assembly Parts




Subassembly (Step 1)



Riding Track B x 1



Riding Track C x 1



Hold and lift the lower end of the subassembly (step 1) above the riding track 2, align them and apply steady downward pressure on the subassembly until it attaches with the riding track B.

Note: Make sure the riding track B is positioned correctly, following the orientation as shown in the images above.



Attach the open end of the riding track B to the riding track C as shown in the images above.

Note: Make sure the riding track C is positioned correctly, following the orientation as shown in the images above.

Your Roller Coaster is now ready for use! You are set to have exciting playtime!

