



UNICORN SLIDE-SENIOR

Instruction

Maintenance & Instructions

- Check all nuts & bolts for tightness & tighten when required. Please keep this instruction for future reference.
- Check all coverings and bolts for sharp edges and replace them when required.
- Check swing seats, chains, ropes, and other means of attachment for evidence of deterioration.
- Replace when required by the manufacturer's instructions.
- Before each use, please check whether the components are firm and intact. Please wipe with a dry cloth regularly.

Caution

- Ensure the product is in good condition and all parts are complete before use.
- After adult installation, please make sure all parts are securely assembled before allowing children to use it.
- Do not let children play with broken, damaged, or deformed toys to prevent accidents.
- Keep packaging materials away from children, as they are not toys and may pose a danger.
- This toy is designed for domestic use and is suitable for both indoor and outdoor play.

Warnings


- This product must be assembled by an adult. Keep all parts and tools away from children until fully assembled.
- The package contains small parts and hardware that pose a choking risk and may have sharp edges or points. Handle with care.
- This product is designed for children aged 24 months and above.
- To prevent serious injury, adult supervision is mandatory at all times. Never leave children unattended during use.
- Ensure children wear shoes while using the product. Limit use to one child at a time, with a maximum weight capacity of 30 kg. Avoid using the slide in areas that are unsafe for pedestrians or near hazards such as swimming pools, steps, roads, hills, or inclines.
- Do not install this equipment over hard surfaces like concrete or asphalt. Place the slide on a stable and appropriate surface, such as grass or a rubber mat.
- Ensure the equipment is on a level surface, at least 7 feet away from structures, walls, pools, power lines, overhangs, other playground equipment, driveways, or roads.
- Do not attach objects like jump ropes, chains, clotheslines, pet leashes, or cables to the slide. These may cause strangulation or other hazards.
- Children must always sit securely in a forward-facing position while sliding. Do not allow children to stand, walk, or slide backward or while lying down. Do not permit standing on the slide-top frame.

Part Details

List of Parts	No.
Side Panel	2
Large Slide	1
Large Slide hand Support (LH-RH)	2
Small slide	1
Small Slide hand Support (LH-RH)	2
Step	1

List of Parts	No.
Step with Riser	3
Basketball Ring	1
Basketball	1
Basketball Net	1
Eyes Label-set	1
Assembly manual	1

List of Parts	No.
Big Nut	11+2 spare
Small Nut	14+2 spare
Key	2
Small Screw(8x15 mm)	2+1 Spare
Big Screw(8x30mm)	1+1Spare
Washer	1+1Spare



**2+
YEARS**



Customer Support



Assembly Video

Before starting the assembly, please ensure that the part quantity matches the numbers listed in the manual. If you find any discrepancies in the part count or encounter any product-related issues, feel free to reach out to us at +918221001033 or connect with us via WhatsApp in between 9:30-6PM, Monday to Saturday. We're here to assist you!



For details of BIS certification, please visit www.bis.gov.in


DISCLAIMER: ACTUAL PRODUCT COLOR MAY VARY FROM THAT SHOWN IN THE IMAGE

1 STEP

Required Assembly Parts



It is recommended to lay a carpet on the floor to prevent scratches during assembly.



Take large slide shown in the image.
Place large side-hand support-LH on a slide by aligning the threaded pins & holes on the side-hand support as shown in the image.

Tighten the 4 small nuts securely using the provided key, as illustrated in the image.



Flip the assembly upside down, place side-hand support-RH on a slide by aligning the threaded pins & Holes on the side-hand support as shown in the image.
Tighten the 4 small nuts using the provided key, as shown in the image.
Big Slide Assembly is Ready for Further Operations.

2 STEP

Required Assembly Part




Keep design on the top side.



Take small slide shown in the image.


Place small side-hand support-LH on Small slide by aligning the threaded pins & holes on the small side-hand support as shown in the image.
Tighten the 3 small nuts securely using the provided key, as illustrated in the image.



Flip the assembly upside down, place side-hand support-RH on a slide by aligning the threaded pins & Holes on the side-hand support as shown in the image.







Tighten the 3 small nuts using the provided key, as shown in the image.



Small Slide assembly is ready for Further Operations.

3 STEP



Required Assembly Parts



Take Assembled Large Slide (Assembled in step-1) & Assembled small slide (Assembled in step-2), flip upside down shown in the image.

Align both slide and slide as shown in the image.



Tighten the Big Screw with washer with help of screw driver as shown in image.




Flip the Assembly, Tighten the Small Screw both side of slide with help of screw driver as shown in image.


4 STEP

Required Assembly Parts





Take slide (assembled in step 3) and side panel. Insert the threaded part of the slide into the hole on the side panel and tighten the big nut, as shown in the image.



Insert the 1 steps(on Top) & 3 Step with Riser into the provided square holes as shown in the image, and securely tighten the nuts.

Align the side panel onto the step, Step with riser, Slide on otherside align the threaded pins with the holes as shown, and secure it using four large nuts.



Take the basketball ring, Large nut, Align & insert the basketball ring as shown in the image and tighten the nut.



Fix the eye labels on both the side panels at the position as shown in image above.

Your Slide is Ready for Fun.