



UNICORN SLIDE-JUNIOR

Instruction

Maintenance & Instructions

1. Check all nuts & bolts for tightness & tighten when required. Please keep this instruction for future reference.
2. Check all coverings and bolts for sharp edges and replace them when required.
3. Check swing seats, chains, ropes, and other means of attachment for evidence of deterioration.
4. Replace when required by the manufacturer's instructions.
5. Before each use, please check whether the components are firm and intact. Please wipe with a dry cloth regularly

Caution

1. Ensure the product is in good condition and all parts are complete before use.
2. After adult installation, please make sure all parts are securely assembled before allowing children to use it.
3. Do not let children play with broken, damaged, or deformed toys to prevent accidents.
4. Keep packaging materials away from children, as they are not toys and may pose a danger.
5. This toy is designed for domestic use and is suitable for both indoor and outdoor play.

WARNINGS


1. This product must be assembled by an adult. Keep all parts and tools away from children until fully assembled.
2. The package contains small parts and hardware that pose a choking risk and may have sharp edges or points. Handle with care.
3. This product is designed for children aged 24 months and above.
4. To prevent serious injury, adult supervision is mandatory at all times. Never leave children unattended during use.
5. Ensure children wear shoes while using the product. Limit use to one child at a time, with a maximum weight capacity of 30 kg. Avoid using the slide in areas that are unsafe for pedestrians or near hazards such as swimming pools, steps, roads, hills, or inclines.
6. Do not install this equipment over hard surfaces like concrete or asphalt. Place the slide on a stable and appropriate surface, such as grass or a rubber mat.
7. Ensure the equipment is on a level surface, at least 7 feet away from structures, walls, pools, power lines, overhangs, other playground equipment, driveways, or roads.
8. Do not attach objects like jump ropes, chains, clotheslines, pet leashes, or cables to the slide. These may cause strangulation or other hazards.
9. Children must always sit securely in a forward-facing position while sliding. Do not allow children to stand, walk, or slide backward or while lying down. Do not permit standing on the slide-top frame.

Part Details

List of Parts	No.
Side Panel	2
Large Slide	1
Slide Handrail (LH & RH)	2
Small slide	1

List of Parts	No.
Step	3
Step Riser	2
Basketball Ring	1
Ball	1
Sticker Set	1

List of Parts	No.
Assembly Manual	1
Big Nut	10 (2 Spare)
Medium Nut	2 (1 Spare)
Small Nut	12 (2 Spare)
Key	2



Estimated Assembly Time: 10 to 15 Minutes

Model No: 4340

2+ YEARS



Customer Support



Assembly Video

Before starting the assembly, please ensure that the part quantity matches the numbers listed in the manual. If you find any discrepancies in the part count or encounter any product-related issues, feel free to reach out to us at +918221001033 or connect with us via WhatsApp in between 9:30-6PM, Monday to Saturday. We're here to assist you!

IS : 9873 - PART I



CM/L - 9512463818

For details of BIS certification, please visit www.bis.gov.in

DISCLAIMER: ACTUAL PRODUCT COLOR MAY VARY FROM THAT SHOWN IN THE IMAGE

1 STEP

Required Assembly Parts




Large Slide x 1



Slide Handrail (RH & LH) x 2



Small Slide x 1




Small Nut x 10




Key x 1

Before starting the assembly, lay out a carpet on the floor to avoid scratches.




Take the large slide shown in the image.




Keep Cloud design on the top side.


Place the slide handrail onto the edge of the big slide making sure the holes on the slide handrail perfectly align with the threaded pins on the slide.



Put a small nut onto the end of each threaded pin and tighten all nuts one by one with the key, securing both (big slide and handrail) together.




Take the small slide, align its threaded pin with the designated hole at the bottom of the slide handrail and push the small slide up, guiding the threaded pin of the small slide into the hole. Use a small nut to fasten the small slide to the handrail.



Flip the assembly upside down and secure the left slide handrail to the subassembly with five small nuts as shown in the images above.

2 STEP


Required Assembly Parts



Take the slide subassembly (step 1), align the threaded pin on its edge (at the top) with the designated hole on the side panel as shown in the image above and secure them together with a big nut.



Take all the three steps from the packaging and fasten them to the side panel with 3 big nuts, using one big nut for each step.



Turn the subassembly on its side as shown in the image above. Take both the risers and slide them into place between the steps. Note: Make sure the tab on the shorter edge of the riser fits into the rectangular slot on the side panel.



Take the other side panel and secure it to the subassembly with four big nuts as shown in the images above.

3 STEP

Required Assembly Parts



Medium Nut x 1

Key x 1



Eyes label Set x 1



Basketball Ring x 1

Subassembly (Step 2)



Turn the subassembly (step 2) right-side up. Take the basketball ring and fasten it to the subassembly by tightening a medium nut with the key.



Attach the eye label on both the side panels at the position as shown in the image.

Hurray! The slide is ready to take your little one into a world of fun and excitement!